

EZB SERIES HOOKUP, INSTALLATION

NOTES:

1. GROUNDING AND BONDING NOT SHOWN
2. CONDUCTOR SIZE AND WIRE TYPE PER NAMEPLATE CURRENT RATING. CAN BE ONE FEED PER BOILER CB.

