





Generac RV Generator - QP-40

MODEL 4709/5852 GAS




MODEL 4701/5853 LPG



VIEW FROM TOP

NOTE: ALL AIR INTAKES AND EXHAUST OUTLETS MUST BE KEPT CLEAR OF ANY OBSTRUCTIONS. ALL OPEN AREA IS REQUIRED FOR COOLING.

MODEL 4709/5852 GAS



MODEL 4701/5853 LPG

