
Dryer Filter Change





Check your silver label to make sure you order the correct filter kit.



Locate your filters

Turn counterclockwise to release your filter canister

- Your filter is located inside, remove and replace old filter with new one (You will do this on bother filters
- When putting in the new filters make sure it lines up correctly (This may take a few try's)





Follow the steps below to reset the filter alarm:

To reset the filter alarm, you need to enter the service domain and then access the "rHF" section. Please follow the steps carefully.

Table 1 Steps to reset the filter alarm


1 Main page


To disable the Key Lock: Press and hold the SET button for 4 sec

2 Key Lock

"Loc" appears while holding the SET button for 4 sec

- 3 "UnL" appears when key lock is released
- 4 To access service menu (Pb1): Press and hold the menu button for 4 sec.
- 5 "Pb1" appears when service menu is opened





Follow the steps below to reset the service alarm:

To reset the service alarm, you need to enter the service domain and then access the "rHS" section. Please follow the steps carefully.

Table 2 Steps to reset the service alarm

1 Main page

To disable the Key Lock: Press and hold the SET button for 4 sec


2 Key Lock


"Loc" appears while holding the SET button for 4 sec

3 "UnL" appears when key lock is released

4 To access service menu (Pb1): Press and hold the menu button for 4 sec.

5 "Pb1" appears when service menu is opened.





Press the SET button to password section after access the "rHF" section.

8 Enter "171" in the password field

- 9 The press and release button SET: the display will show "- - " 4 sec flashing
- 10 The main page appears after this operation

