

WIFI CONNECTABLE UNITS & MODULES

| | | | |
|---|---|---|--|
|  <p>RLS3Y (Built In WIFI) ASU 9/12/15 RLS3Y</p> |  <p>WIFI Interface Device UTY-TFNXZ2 (Add-on)</p> |  <p>IR Wireless Module FJ-IR-WIFI-1NA (Add-on)</p> |  <p>Wired Module FJ-RC-WIFI-1NA (Add-on)</p> |
|---|---|---|--|

WHICH APP DOES IT USE?

| | | | |
|--|--|--|--|
|  FGLAir |  FGLAir |  Intesis Home |  Intesis Home |
|--|--|--|--|

FGLAIR APP FEATURES:

- | | |
|-------------------------|--------------------------|
| 1. On/Off | 5. Louver/Swing Position |
| 2. Change Mode | 6. Weekly Timer |
| 3. Change Temp Setpoint | 7. Economy Setting |
| 4. Fan Speed | 8. Emailed Error Alerts |

INTESIS HOME APP FEATURES:

- | | |
|-------------------------|--------------------------|
| 1. On/Off | 5. Louver/Swing Position |
| 2. Change Mode | 6. Weekly Timer |
| 3. Change Temp Setpoint | 7. Fully Programmable |
| 4. Fan Speed | 8. Alarm Notifications |

WHERE DOES IT MOUNT?

| | | | |
|----------------------|--------------------------|-------------------------|--------------------------|
| Built into the RLS3Y | On the wall, next to IDU | Up to 20' away from IDU | On the wall, next to IDU |
|----------------------|--------------------------|-------------------------|--------------------------|

COMPATIBLE UNITS:

| WALL MOUNTS: | WALL MOUNTS: | WALL MOUNTS: | WALL MOUNTS: |
|---------------------------------------|--|---|---|
| ASU9RLS3Y ASU12RLS3Y ASU15RLS3Y | ASU 7 / 9 / 12RLF ¹ ASU 7 / 9 / 12 / 15RLF1 ² ASU 9 / 12 / 15RLS2 ³ ASU 9 / 12 / 15RLS3 ³ ASU 18 / 24RLF ASU 30 / 36CLX1 ASU30RLX ASU 18 / 24RLB ASU 30 / 36RLXB ASU30RLE CASSETTES: AUU 7 / 9 / 12 / 18RLF DUCTED: ARU 7 / 9 / 12 / 18 / 24RLF FLOOR MOUNTS: AGU 9 / 12 / 15RLF | ASU 7 / 9 / 12RLF ASU 7 / 9 / 12 / 15RLF1 ASU 9 / 12 / 15RLS2 ASU 9 / 12 / 15RLS3 ASU 18 / 24RLF ASU 30 / 36CLX1 ASU30RLX ASU 18 / 24RLB ASU 30 / 36RLXB ASU 9/12RL2 ASU 18CL / 24CL1 CASSETTES: AUU 7 / 9 / 12 / 18RLF DUCTED: ARU 7 / 9 / 12 / 18 / 24RLF ⁴ FLOOR MOUNTS: AGU 9 / 12 / 15RLF UNIVERSAL / CEILING: ABU 18 / 24RULX ABU36RSLX | ASU 7 / 9 / 12RLF ⁶⁺⁷ ASU 7 / 9 / 12 / 15RLF1 ⁶⁺⁷ ASU 9 / 12 / 15RLS2 ⁶⁺⁸ ASU 9 / 12 / 15RLS3 ⁶⁺⁸ ASU 18 / 24RLF ASU 30 / 36CLX1 ASU30RLX ASU 18 / 24RLB ASU 30 / 36RLXB ASU 18CL / 24CL1 CASSETTES: AUU 7 / 9 / 12 / 18RLF AUU 18 / 24 / 36 / 42RCLX DUCTED: ARU 7 / 9 / 12 / 18 / 24RLF FLOOR MOUNTS: AGU 9 / 12 / 15RLF ⁶ UNIVERSAL / CEILING: ABU 18 / 24RULX ABU36RSLX |
| Possibly Also Needed: | ¹ requires UTY-XCBXZ1 ² requires UTY-XCSXZ2 ³ requires UTY-TWBXF1 | ⁴ requires UTY-LRHUM | ⁶ requires UTY-WIFI ⁷ requires UTY-XCBXZ2 ⁸ requires UTY-TWBXF1 |