

# **REZNOR**°

# Vertical Vent Terminal/Combustion Air Inlet Assembly (Option CC2)





**REAR VIEW** 

**SIDE VIEW** 

## **REZNOR**°


## **Horizontal Vent Terminal/Combustion Air Inlet Assembly**

(Option CC6)


Approved vent terminals are illustrated below. No other venting arrangements are approved or certified for use with Reznor separated combustion heaters.

Both the horizontal and vertical assemblies include: concentric adapter, screened exhaust or cap, inlet ring or inlet cap, rubber gasket ring and a tube of high temperature silicone rubber sealant; all shipped separately.

### **TOP VIEW**



#### **SIDE VIEW**



\*Minimum - Check for and comply with local Codes.

